


## Prografx Snowmobile Decal Kit Installation Instructions


Thank you for purchasing one of our custom graphics kits! We value your business and wish you the best wherever your ride takes you.

Your package includes your decal kit, a squeegee to assist you with the installation process, and a decal position reference sheet. Please be sure to read the following instructions carefully before beginning to install your graphics to ensure the best results.


### Before you begin, you will need the following items:



X-acto knife



Sharp Scissors




Squeegee (provided)



Masking Tape



Heat Gun or Hair Dryer



Paper Towels



Glass Cleaner

**IMPORTANT NOTE:** Please be advised that prografx.ca is not responsible for any damage to decals that occurs during your installation (i.e. wrinkling, creases). Please use care, patience, and follow the installation instructions to ensure the best possible results. Any damage caused during shipping must be reported immediately, and prior to installation. If your kit was damaged, please call us at 519-620-8033.

**STEP 1:** Remove your graphics from the box and lay them flat and at room temperature, for 1-2 hours before installing. Your graphics have been shipped rolled up, in one piece to avoid any damage, or wrinkling during shipping.

### **STEP 2: Clean and prep your panels.**

- A) Your panels should be brought inside, on a bench, at room temperature (70 degrees F)
- B) All grease, oil, adhesive, silicone protectants, dirt and residue must be removed. This can be done with cleaners such as varsol, spray nine, or other degreasers that won't harm the plastic.
- C) Clean the panels with glass cleaner and let them dry thoroughly.
- D) **Do the clean towel test** - if you can rub a clean white towel over the panels without seeing any residue appear on the towel, the area is sufficiently clean.

### **STEP 3 : Plan your installation**

Review your kit pieces and familiarize yourself with the location of each piece.

There is a print out provided with your kit. This shows the positioning for each decal panel.

**Note:** There are often left and right pieces that will only fit one side of the sled.

### **STEP 4**

**Using a heat gun, warm the decals on the panel so that they are warm to the touch. This application of heat will soften the adhesive and strengthen the bond to the panel.**

### **STEP 5**

Inspect all decals and make sure all edges and corners are bonded to the surface. Bubbles can be poked with a pin and the air worked out by pressing down with your finger.

**Using your exacto knife, trim any edges or corners that hang past the edge of the panel.**

## Important Note About Installing our Product



We have partnered with 3M on a new product that greatly reduces the difficulty of installing our graphics. All of our sled wrap products now use a patented high tack adhesive that has minute channels in it that allow for easier positioning and drastically reduces the possibility of air bubbles during installation.

As a result there is no need to use an application fluid such as soap and water when installing. In fact, the use of liquids during installation will make it more difficult to install and may cause product failure due to reduced adhesion to the mounting surface.

**It is strongly recommended that all graphics be applied dry and then be heated and rubbed onto each panel after application to increase the bond of the adhesive to each panel.**

Failure to do so may result in an insufficient bond to the mounting surface and ultimately failure of the product.

## Decal Positioning / Order of Installation

**NOTE: Not all kits contain all the pieces shown below.**

